

Installation Instructions

1. Align the vinyl wraps to desired position on the board, checking all corners and the middle hole.
2. Tape vinyl wraps to the boards at the center.
3. Lift one side, peel and cut off adhesive backing and apply w/ a soft rubber/felt squeegee. Remove center tape and do the same for the other side.
4. Once installed with soft rubber squeegee, you should see no air bubbles. Now roll the entire board with a hard rubber roller while applying heat to activate the curing process.
5. Trim off the sides and then apply at least 2+ coats of polycrylic or waterbased clear coat.
6. Let dry and cure for a full 8 hours before transporting or playing on the boards
7. Enjoy!

For Questions

Call:

Toll Free: 1-877-459-9035

Direct: 1-407-203-6886

Installation Instructions

Items Needed:



Ensure the surface of the boards are dry, smooth and debris free.
You **MUST** use heat during installation to activate the curing process.
You **MUST** use a soft rubber or felt tipped squeegee, not hard plastic.
You should not see **ANY** air bubbles after installation is complete.
Do **NOT** stretch the vinyl.

We are not responsible for incorrect installations or mistakes. All sales are final.